




545535C

To download, brochures, catalogues and technical manuals:
www.socomec.com/operating-instructions
www.socomec.com




RJ12 / RJ45 cables kits - Termination instructions

1 Select the appropriate cable kit (RJ45 - 8 pin or RJ12 - 6 pin). Please note that only Socomec kits should be used.



or



2 Cut the cable to the required length.


3 Remove 1cm of insulation from each end.

4 Place cable into RJ45 plug (8 wires) or RJ12 plug (6 wires) in the configuration below:

RJ45 colour order	Cable to be laid in to connector as below:
1 White/Orange 2 Orange 3 White/Green 4 Blue 5 White/Blue 6 Green 7 White/Brown 8 Brown	

RJ12 colour order	Cable to be laid in to connector as below:
1 Red 2 Blue 3 Green 4 Brown 5 Orange 6 Black	

5 Secure the plugs using an appropriate tool:



6 Test to ensure that all pins show continuity using a suitable appliance, RJ45 cable (8 pin test) or RJ12 (6 pin test):

